RETEKESS

Motion Sensor Doorbell With Customized Voice

Instructions

Model: TD107

Honan Extreme Electronic Commerce Co., Ltd
No. 37, Guanyu Building, No.170 Nanyang Road, Huaji District,
Zhengzhou, Henan, China
Tel: +86-371-67992697
Email: service@retekess.com
Website: www.retekess.com

CE FC RoHS

Warranty Card

Product model: _____ Date of purchase: _____
Serial Number: _____
Seller: _____ contact number: _____
Username: _____ contact number: _____
Address: _____ Zip code: _____

Warranty description:

1. The warranty card is saved by the customer as the
2. Please modify the date and fill in the seller's contact
3. This card must be stamped and valid for sale to take
4. This card must not be altered. Please keep the card for
5. The warranty period is one year. Chargers, batteries,
6. Users can choose the following ways to repair:
   A. At the original purchase office.
   B. Our company is in the local special maintenance point

1

▲ Welcome guests / doorbell, alarm, motion sensor lighting 3 in 1 design, welcome guests in the daytime, guard against theft at night in the night.

▲ Wireless doorbell, push button 2 way, DIY voice recording, 52 MP3 music built-in, can be connected to the computer to download.

▲ Support WAV and MP3 formats, 40mm loudspeaker, play warning voice or promotional advertisements or store names, suitable for various occasions.

▲ AAA batteries Rechargeable batteries/Micro USB power interface to supply power.

3 in 1 Doorbell / Welcome / Motion Sensor
WAV MP3 52 Built-in Songs
Built-in Rechargeable Battery
Custom Recording
No Wiring
Micro USB Power Supply
Waterproof

Suggestions for application: Banks, subway stations, schools and other public places, convenience stores, companies, families, etc., More uses waiting for you to explore!

2

2. Function Description:

2.1 Install batteries

2.1.1 Install 3pcs AAA batteries or rechargeable Ni-MH battery, please pay attention to the positive and negative poles of the battery, open the battery door and insert batteries, batteries work well for 6M+ recommended.

2.1.2 After the battery is installed, the LED flashes and prompts, "Please set the doorbell code", indicating that it is in code matching state.

2.1.3 Make the batteries recommended by the manufacturer, and do not use old and new batteries together. Ni-MH rechargeable batteries work normally in the low temperature environment, and the battery life will be reduced. Please remove the batteries when not in use for a long time to prevent battery leakage from damaging the product. Please use a multimeter to measure the battery voltage. When the battery voltage is lower than 3.6V, please replace the batteries in time to ensure the normal use of the doorbell. Rechargeable batteries will be more than double-priced replacement batteries, but more environmentally friendly.

2.1.4 Micro USB power interface, can be connected to the external signal adapter, it is released from the battery power supply, the battery will not be charged in the direction of the external power supply, suitable for 5V/1A power supply, DC power and battery can automatically stand by and switch.

2.2 Install the doorbell

2.2.1 Install the welcome doorbell in the indoor location, or at one side of the entrance where customers can hear clearly, and the signal is not blocked by metal products, please install in the appropriate location according to the actual situation, the antenna will be more than double-sided tape installation after the screw is fixed.

2.2.2 When installed, press turn on key of the host to enter into

3

2.3 Download voice

1. Connect to the computer via Micro USB cable.
2. Open the "My Computer" or "This PC" and click on it, a file suffixes name of 52 MP3 files will be displayed, and a file named "VOICE" will be displayed, double-click to open the "VOICE" folder, you can open the removable disk icon. (Incompatible with Mac computer)

3. Copy the prepared WAV or MP3 format sound into the mobile disk. The file name must be the same as the U-DISK. Please play after the file is copied.
4. After the copy is completed, pop up the disk, unplug the USB cable, install the host in the base.

4

2.3.2 Memory function when power off

Power on default in maximum volume, the songs and the volume will be memorized when power off, the next time the power is turned on.

2.4 Switch mode

Turn on the host, short press **1** Key to switch mode, "Welcome Doorbell + Motion Sensor Alarm" → "Doorbell Mode" → "Motion Sensor Alarm" → "Doorbell + Motion Sensor Alarm" in reverse after the host is turned on, every time it is switch mode.

5

2.5 Volume adjustment

Short press **2** key to adjust the volume, there are 5 levels of volume, the system will remember the volume when power off.

2.6 Select songs

Short press **3** key to switch songs, "Welcome Doorbell + Motion Sensor Alarm" mode, you can switch the doorbell songs, "Doorbell Mode" can switch the doorbell songs, "Motion Sensor Alarm" mode can switch the alarm songs, "Doorbell + Motion Sensor Alarm" mode can switch the doorbell and alarm songs.

2.7 Parameters

2.7.1 Power supply of the host: 2*AAA alkaline batteries or Rechargeable batteries (not included)

2.7.2 Battery lifespan: 1 month(Alkaline batteries)

2.7.3 Working current: 60mA

2.7.4 Working temperature: -10°C~+50°C

2.8 Reset

Press and hold the **#** key for 5 seconds, the host will restore the factory default settings, and the doorbell code will be cleared.

2.9 Add a doorbell

Press and hold the **3** key for 5 seconds, the host will enter the code matching state, and the doorbell will enter the code matching state, and the doorbell will enter the code matching state, and the doorbell