

IC Requirements:

Licence-exempt radio apparatus

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Information

- DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio, and the antenna gain shall not exceed the specified gain by the manufacturer declared.
- DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded.
- During transmissions, your radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so.
- The device complies with RF specifications when the device used at 5mm from your body. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.
- DO NOT operate the transmitter in areas that are sensitive to electromagnetic radiation such as hospitals, aircraft, and blasting sites.

Avoid Choking Hazard



Small Parts. Not for children under 3 years.

Protect your hearing:



- Use the lowest volume necessary to do your job.
- Turn up the volume only if you are in noisy surroundings.
- Turn down the volume before adding headset or earpiece.
- Limit the amount of time you use headsets or earpieces at high volume.
- When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear
- Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss



Note: Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the radio's volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect.

Avoid Burns



Antennas

- Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with the skin when the radio is in use, a minor burn can result.

Batteries (If appropriate)

- When the conductive material such as jewelry, keys or chains touch exposed terminals of the batteries, may complete an electrical circuit (short circuit the battery) and become hot to cause bodily injury such as burns. Exercise care in handling any battery, particularly when placing it inside a pocket, purse or other container with metal objects

Long transmission

- When the transceiver is used for long transmissions, the radiator and chassis will become hot.

Safety Operation



Forbid

- Do not use charger outdoors or in moist environments, use only in dry locations/conditions.
- Do not disassemble the charger, that may result in risk of electrical shock or fire.
- Do not operate the charger if it has been broken or damaged in any way.
- Do not place a portable radio in the area over an air bag or in the air bag deployment area. The radio may be propelled with great force and cause serious injury to occupants of the vehicle when the air bag inflates.

To reduce risk

- Pull by the plug rather than the cord when disconnecting the charger.
- Unplug the charger from the AC outlet before attempting any maintenance or cleaning.
- Contact Reteless for assistance regarding repairs and service.
- The adapter shall be installed near the equipment and shall be easily accessible
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- Adapter shall be installed near the equipment and shall be easily accessible.
- The plug considered as disconnect device of adapter.
- The operating temperature of the EUT can't exceed the specified range.

Approved Accessories



- This radio meets the RF exposure guidelines when used with the Reteless accessories supplied or designated for the product. Use of other accessories may not ensure compliance with the RF exposure guidelines and may violate regulations.
- For a list of Reteless-approved accessories for your radio model, visit the following website: <http://www.Reteless.com>

RETELESS

TD121/TD122

Wireless Calling Receiver User Manual

EU Importer

Name: Germany Retevis Technology GmbH
Address: Uetzenacker 29,38176 wendeburg

Henan Eshow Electronic Commerce Co., Ltd

Add: 7/F, Sanjiang Building, No.170 Nanyang Road, Huiji District, Zhengzhou, Henan, China

Specification

Parameter Introduction			
Specification	24/60 ports	Operation frequency	433.92MHz
Display	LED tube	Button	SETUP, UP, DOWN, ENTER, CLEAR
Volume	Adjustable Digital-control for 10 levels	Operation conditions	Environmental temperature: Degree 0-40 Relative humidity: less than 80%
Times for prompt tone	0-99 times	Partition function	xxxRoom + xxx Bed

Restore factory value after power on

Plug the power in the box into the socket, and a small head on the other end of the power supply is inserted into the DC hole of the main engine. Long press the "SETUP" button in the standby state. Then the screen shows "F1" and press "UP" button to "F2", press "ENTER" once to make sure the host appears "0001", in which the bit of digital tube is flashing, and press "DOWN" button to make the screen display as "0000", then long press "CLEAR" button, at the same time, the number on the screen is beating automatically, which means it is recovering Factory value, the host screen is restored to standby state after cleaning.

Set the time F1

1. Long press "SETUP" button, the screen shows "F1"
2. Short press "ENTER" button to shift, press "UP/DOWN" button to select current time of year, month, day and week.
3. Press the "SETUP" button twice, and the host screen is restored to standby state.

Caller registration number F2

1. When the host machine is in standby mode, long press the "SETUP" button, and the host screen will display "F1", then press "UP" button turn to "F2"
2. Press the "ENTER" button once, and the display screen will appear "0001".
3. Use "UP/DOWN" and "ENTER" buttons shift to select the number of the bed and room to register.
4. Press the call button for about one second, the number displayed on the screen will automatically jump to the next one to register the next beeper.
5. If you need to set other Numbers, use the "UP/DOWN" and "ENTER" button to shift to select the number to be registered.
6. After the code matching is completed, press the "SETUP" button twice to return to the standby state.

Set the prompt music length F3

1. Long press the "SETUP" button to enter the setting menu, the screen displays "F1", then press the "UP" button to "F3".
2. Press "ENTER" button, and use the "UP/DOWN" button to select the prompt time from 00-99, if you set it as "00" which means mute with no voice prompt.

Single delete caller

Long press the "SETUP" button to enter the setting menu, the screen displays "F1", then press the "UP" button to "F2", press "ENTER" button, then use "UP/DOWN" button to select the number you want to delete, press "CLEAR" button to delete it.

Volume

When the host machine is in standby mode and displays time (year/month/day), select "UP/DOWN" button to adjust the volume(0-10) available. The volume cannot be adjusted if the calling information is displayed on the screen, press the "CLEAR" button return to standby mode to adjust the volume.

Set the loop display time F4

1. Long press the "SETUP" button to enter the setting menu. The screen Displays "F1", press the "UP" button to "F4"
2. Short press the "ENTER" button to enter sub-menu choice, use "UP/DOWN" button to select the loop display time from 00 to 99.
3. After setting, press the "SETUP" button twice to return to the standby state.


Set auto clear time F5

1. Long press the "SETUP" button to enter the setting menu. The screen displays "F1" Press the "UP" button to "F5".
2. Short press the "ENTER" button to enter sub-menu choice, use "UP/DOWN" button to set the time to clear automatically.
3. After setting, press the "SETUP" button twice to return to the standby state.

Set the prompt music F6

1. Long press the "SETUP" button to enter the setting menu. The screen displays "F1". Press the "UP" button to "F6"
2. Short press the "ENTER" button to enter sub-menu to select the prompt music from 0 to 3 by pressing "UP/DOWN" button.
3. After setting, press the "SETUP" button twice to return to the standby state.

Warnings



This radio uses electromagnetic energy in the radio frequency (RF) spectrum to provide communications between two or more users over a distance. RF energy, which when used improperly, can cause biological damage.

All Reteless radios are designed, manufactured, and tested to ensure they meet government-established RF exposure levels. In addition, manufacturers also recommend specific operating instructions to users of the radios. These instructions are important because they inform users about RF energy exposure and provide simple procedures on how to control it.

Please refer to the following websites for more information on what RF energy exposure is and how to control your exposure to assure compliance with established RF exposure limits: <http://www.who.int/en/>

Local Government Regulations

When radios are used as a consequence of employment, the Local Government Regulations requires users to be fully aware of and able to control their exposure to meet occupational requirements. Exposure awareness can be facilitated by the use of a product label directing users to specific user

awareness information. Your Reteless radio has a RF Exposure Product Label. Also, your Reteless user manual, or separate safety booklet includes information and operating instructions required to control your RF exposure and to satisfy compliance requirements.

Radio License (if appropriate)

Governments keep the radios in classification, business radios operate on radio frequencies that are regulated by the local radio management departments (FCC, ISED, OFCOM, ANFR, BFTK, Bundesnetzagentur...). To transmit on these frequencies, you are required to have a license issued by them. The detailed classification and the use of your radios, please contact the local government radio management departments. Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.

Unauthorized modification and adjustment

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority granted by the local government radio management departments to operate this radio and should not be made. To comply with the corresponding requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services. Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the local government radio management departments equipment authorization for this radio could violate the rules.

FCC Requirements:

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE Requirements:

- (Simple EU declaration of conformity) Henan Eshow Electronic Commerce Co.,Ltd declares that the radio equipment type is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU and the ROHS Directive 2011/65/EU and the WEEE Directive 2012/19/EU; the full text of the EU declaration of conformity is available at the following internet address: www.reteless.com.
- Disposal

The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that in the European Union, all electrical and electronic products, batteries, and accumulators (rechargeable batteries) must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws in your area.